



RAMTOP

Here is a layout guide for the 1500 and 1000. If you would like to add a jack to your computer to get a monitor output, it is very simple! In the case of the 1000, simply solder a 47 MF cap rated at least 16 volt (+ side) to pin 16 of the ULA chip. The other side of the cap (- side) goes to the center of an RCA jack. The sleeve of the jack goes to metal can of the modulator. In the case of the 1500, instead of connecting to the ULA chip, you connect to the lower side of D-19. (it's marked on the board) The other connections are the same. The 1000/1500 actually has a cleaner video than the 2068! It is also fairly easy to convert your B & W TV to a monitor. You should use a TV that is isolated from the AC line. Almost all portable or 12 volt models will work. If you want to do this, give me a call for more details. You may also want to install a Reset switch. If so, refer to the April RAMTOP. DON'T ATTEMPT THIS UNLESS YOU HAVE A BIT OF ELECTRICAL KNOWLEDGE! THIS IS ALSO, AT YOUR OWN RISK!

TS-1500



TS-1000



SPECTRUM CALLS AND POKES

Here are a selection of POKES and ROM calls for the Spectrum that produce some interesting effects without upsetting the machine.

Justin Moffitt

POKE 23756,0.....Makes first line line 0
POKE 23756,1.....Makes line 0 line 1
POKE 23609,25.....Makes keyboard bleep
POKE 23609,0.....Makes keyboard silent
POKE 23658,8.....Turns CAPS LOCK on
POKE 23658,0.....Turns CAPS LOCK off
POKE 23755,100.....Disables list command
POKE 23755,0.....Re-enables list command
1 POKE 23659,0.....Makes 24-line screen
9999 POKE 23659,2.....Makes 22-line screen again
POKE 23736,181.....Stops the START TAPE prompt

POKE 23692,255.....Stops the SCROLL ? prompt
POKE 23613,0.....Disables BREAK key, so when it is pressed the program hangs up
POKE 23613,PEEK(23730)-5.....Disables BREAK completely
LET t=USR 3582.....Scrolls screen one line
LET t=USR 4757.....Prints the Sinclair prompt, but does not clear the RAM
LET t=USR 3213.....Stops and asks, SCROLL ?
LET t=65536-USR 7962.....Prints free memory in bytes
LET t=USR 3583.....Scrolls bottom half of screen one line
LET t=USR 3652.....Clears top half of screen
LET t=USR 3330.....Scrolls whole page to top line, must be followed by CLS
POKE 23617,236.....Changes cursor to ?
OUT 10,colour.....Changes BORDER colour to f, and gives a CLICK, useful for routine when a game has been won
POKE 23617,14.....Changes cursor to _
LET t=USR 1331.....Gives special border effect in magenta and blue
LET t=USR 1290.....Gives special border effect in blue and red
LET t=USR 1269.....Gives special border effect with special sounds
LET t=USR 1251.....Gives border effect in green and magenta
LET t=USR 1551.....Gives a list of programs on tape
LET t=USR 1248.....Gives border effect in white and black
LET t=USR 1333.....Gives border effect in cyan and blue
LET t=USR 1327.....Gives border effect in white and blue
LET t=USR 1267.....Gives border effect in blue and yellow

LET time=(65536*PEEK 23674+256*PEEK 23673+PEEK 23672)/60 for US
Gives time in seconds since the computer was turned on, and only resets every four days

Using the 'border effects'

The border effects give the effect of the save bars in different colours. They only stop after SPACE has been pressed, but some contain a delay loop as well.

For example:
10 PAPER 1:INK 7:LET t=USR 1333:CLS
15 REM rest of program

TO SUBSCRIBE TO THE RAMTOP, SIMPLY FILL THIS HANDY FORM OUT AND SEND IT ALONG WITH YOUR CHECK FOR \$7.50/6 MO. OR \$15.00/YEAR OR IF YOU ARE OUT OF OUR AREA, THE COST IS \$6/6 MO. AND \$12/ YEAR. MAKE CHECKS PAYABLE TO THE RAMTOP.

**PLEASE PRINT!!! CHECK ONE- 6 MONTH___ 12 MONTH___ **
** We publish every month! **
** **
**NAME _____ **
** **
**ADDRESS _____ **
** **
**CITY _____ STATE _____ ZIP _____ **
** **
**TYPE OF COMPUTER(S) _____ **
** **
**OTHER PERIPHERALS _____ **
**Mail to: Robert Parish, 12706 Leeila Ave., **
** Cleveland, OH 44135 **
